

■ Willcom Co.,LTD 車載用DC充電器シリーズ ■

- ★該当品番：MB-83 / MB-69 / MB-95 / MB-98 / MB-99CB …… MicroUSB外部接続端子
 - ★該当品番：MB-83 / MB-69 / MB-95 / MB-98 / MB-99CB /
MB-100/MB-101/MB-102/MB-103/MB-104 …… MicroUSB端子
 - ★該当品番：MB-89 / MB-87 / MB-68 / MB-96 …… Dock端子
 - ★該当品番：MB-31 / MB-33 / MB-78 …… Foma/SoftBank
 - ★該当品番：MB-30 / MB-32 / MB-77 …… au
 - ★該当品番：M85 / MB-86 / MB-88 / MB-53 / MB-97 / MB-34 …… マルチ(複数機種)端子
- ※ マルチ(複数機種)端子は各携帯ごとの適合を確認下さい。
 ※一部のスマートフォンや携帯電話は、防水機能などにより、コネクタが奥までささらない場合がございますので、ご注意ください。

注:ADC-03トラベルチャージャーⅢ非適合機種(内蔵リチウム電池ご使用時)

docomo Foma

SAMSUNG

SC-06D

スマートフォン用

※MicroUSB端子

※該当品番：MB-83 / MB-69 / MB-95 / MB-98 / MB-99CB
MB-100/MB-101/MB-102/MB-103/MB-104

※1 「USB Type-C」コネクタ対応機種のため、「microUSB変換アダプタ B to C 01」等の
変換ケーブルを使用した場合は対応しております。

docomo

TOSHIBA

T-02D / T-01C / T-01B / T-01A

SonyEricsson

SO-04E / SO-02E / SO-04D / SO-05D / SO-03D / SO-02D / SO-01D / SO-03C
SO-01C / SO-02C / SO-01B

SONY

SO-04J ※1 / SO-03J ※1 / SO-02J ※1 / SO-01J ※1 / SO-04H / SO-03H / SO-02H / SO-01H / SO-04G
SO-03G / SO-02G / SO-01G / SO-04F / SO-03F / SO-02F / SO-01F / SO-01E

SHARP

SH-03J ※1 / SH-02J / SH-04H / SH-02H / SH-01H / SH-04G / SH-03G / SH-02G / SH-01G / SH-05F / SH-04F
SH-03F / SH-02F / SH-01F / SH-07E / SH-06E / SH-05E / SH-04E / SH-02E / SH-01E / SH-10D
SH-09D / SH-07D / SH-06D / SH-02D / SH-01D / SH-12C

SAMSUNG

SC-04J / SC-03J ※1 / SC-02J ※1 / SC-02H / SC-01H / SC-04G / SC-05G / SC-01G / SC-02G / SC-04F
SC-02F / SC-01F / SC-04E / SC-03E / SC-02E / SC-06D / SC-05D / SC-04D / SC-03D / SC-02C / SC-02B
SC-01B

Research In Motion

BlackBerry 9900 / BlackBerryBold 9780
BlackBerry Curve 9300 / BlackBerryBold9700

LG

L-01J ※1 / Nexus 5X ※1 / L-01F / L-05E / L-04E / L-02E / L-01E / L-06D / L-05D / L-02D / L-01D / L-03C
L-04C / L-07C

NEC

N-06E/N-05E/N-04E/N-03E/N-02E(ONE PIECEモデルも含む)/N-07D
N-05D/N-04D/N-01D

Panasonic

P-03E/P-02E/P-07D/P-06D/P-04D/P-05D/P-02D/P-01D/P-07C

FUJITSU

F-05J/F-04J/F-01J/F-03H/F-02H/F-01H/F-04G/F-02G/F-06F/F-05F/F-04F/F-03F/F-01F
F-09E/F-08E/F-07E/F-06E/F-02E/F-12C/F-03E/F-04E/F-11D/F-12D/F-10D/F-09D
F-08D/F-07D/F-05D/F-03D

HUAWEI

HW-03E/HW-01E

Disney Mobile On Docomo

DM-01J/DM-02H/DM-01H/DM-01G

ZTE

MO-01J

au

TOSHIBA

IS11T/IS12T/IS04/IS02

SHARP

SHV39 ※1/SHV38/SHV37/SHV36/SHV35/SHV34/SHV33/SHV32/SHV31/SHL25/SHT22/SHL24
SHL23/SHL22/SHL21/IS17SH/IS15SH/ISW16SH/C01/IS14SH/IS13SH/IS12SH/A01/IS11SH/IS05
IS03/IS01

PANTECH

PTL21/IS11PT/IS06

HTC

HTV33 ※1/HTV32 ※1/HTV31/HTL23/HTL22/HTL21/A02/ISW13HT/ISW12HT/ISW11HT

SonyEricsson

IS12S/IS11S

SONY

SOV35 ※1/SOV34 ※1/SOV33/SOV32/SOV31/SOL26/SOL25/SOL24/SOL23/SOL22/SOL21

CASIO

CAL21/IS11CA

MOTOROLA

IS12M/ISW11M

KYOCERA

KYV42/KYV41 ※1/KYV40/KYV39/V03(KYV38)/KYV37/KYV36/G02(KYV35)/V02(KYV34)/A03/KYV32
KYL23/V01(KYV31)/G01(KYY24)/L03(KYY23)/L02(KYY22)/KYL22/L01(KYY21)/KYL21/KYY04/ISW11K

FUJITSU

FJL22/FJL21/ISW13F/IS12F/ISW11F

NEC

IS11N

LG

LGV34 ※1 / LGV33 / LGV32 / LGV31 / LGL24 / LGL23 / LGL22 / LGL21 / IS11LG

SAMSUNG

SCV36 ※1 / SCV35 ※1 / SCV33 / SCV32 / SCV31 / SCT21 / SCL24 / SCL23 / SCL22 / SCL21 / ISW11SC

FirefoxOS(LG)

LGL25

SoftBank**TOSHIBA**

X02T

SHARP

606SH / 605SH ※1 / 603SH / 509SH / 506SH / 503SH / 502SH / 403SH / 404SH / 402SH / 401SH / 305SH
304SH / 303SH / 302SH / 206SH / 205SH / 204SH / 203SH / 200SH / 107SH / 102SH II / 106SH / 104SH
103SH / 102SH / 101SH / 009SH / 005SH / 006SH / 007SHJ / 007SH / 003SH

SONY

602SO ※1 / 601SO ※1 / 502SO / 501SO / 402SO / 401SO

SAMSUNG

404SC / X01SC / 830SC

HTC

601HT ※1 / 001HT / X06HT・X06HT II

ZTE

402ZT / 009Z / 003Z / 008Z

Panasonic

102P / 101P

NEC

101N

KYOCERA

602KC / 503KC / 404KC / 202K / 201K / 101K

HUAWEI

201HW / 007HW

DELL

101DL

FUJITSU

301F / 202F / 201F / 101F

MOTOROLA

201M

Disney Mobile On SoftBank

DM016SH / DM015K / DM014SH / DM009SH / DM010SH / DM011SH / DM012SH / DM013SH

E-MOBILE**HTC**

S31HT

HUAWEI

GL07S / GS03 / GS02 / S31HW / S42HW

SonyEricsson

S51SE

DELL

GS01

FUJITSU

EM01F

WILLCOM**KYOCERA**

WX10K / WX06K / WX04K

SHARP

WX05SH / WX04SH

HUAWEI

201HW

Y!mobile**HUAWEI**

503HW / 302HW

KYOCERA

S2 / 503KC / 404KC / 302KC

MOTOROLA

Nexus6

LG

402LG

SHARP

X1 ※1 / S1 / 507SH

その他**LG**

NEXUS5

HUAWEI

Nexus 6P ※1

従来型携帯電話 (microUSB端子)

※MicroUSB端子

※該当品番 : MB-83 / MB-69 / MB-95 / MB-98 / MB-99CB

MB-100 / MB-101 / MB-102 / MB-103 / MB-104

docomo**FUJITSU**

F-02J / F-05G

SHARP

SH-01J / SH-06G

Panasonic

P-01J

au**KYOCERA**

KYF36/KYF35/KYF34/KYF33/KYF32/KYF31/KYY10/KYY09/KYY08/KYY06

SHARP

SHF33/SHF32/SHF31

SoftBank**KYOCERA**

501KC

SHARP

601SH/505SH/501SH

ZTE

302ZT

WILLCOM**KYOCERA**

WX11K/WX12K

SII

WX04S

Y!mobile**KYOCERA**

402KC/401KC

iPhone用

※Dock端子

※該当品番 : MB-89 / MB-87 / MB-68 / MB-96

iPhone 4S/3GS/3G

従来型携帯電話**docomo Foma**

※該当品番 : MB-31 / MB-33 / MB-78

NECN-01G/N-01F/N-01E/N-02D/N-03D/N-05C/N-03C/N-02C/N-01C/N-08B
N-07B/N-06B/N-05B/N-04B/N-03B/N-02B/N-01B/N-09A/N-08A/N-07A/N-06A
N-05A/N-04A/N-02A/N-01A/N-03A/N706iII/N706ie/N706i/N906i/N906i μ
N705i μ /N705i/N905i μ /N905i/N704i μ /N904i/N703i μ /N703iD
N903i/N902iX/N702iS/N902iS/SIMPURE N1(N601i)/N702iD/N902i
N701i/N901iS/N901iC/SIMPURE N(N600i)**Panasonic**P-01H/P-01G/P-01F/P-01E/P-03D/P-04C/P-03C/P-02C/P-01C
P-07B/P-06B/P-05B/P-04B/P-03B/P-02B/P-01B/P-10A/P-09A/P-08A/P-07A
P-06A/P-04A/P-02A/P-03A/P-01A/P706ie/P706i μ /P906i/P705iCL/P905iTV
P705i μ /P705i/P905i/P704i/P704i μ /P904i/P903iX/P903iTV/P703i μ /P703i
P903i/P702iD/P902iS/P901iTV/P702i/P902i/P851i/P701iD/P901iS/P901i

SHARP

SH-07F/SH-03E/SH-05D/SH-03D/SH-10C/SH-11C/SH-06C/SH-05C/SH-04C/SH-02C
SH-01C/SH-09B/SH-08B/SH-07B/SH-06B/SH-05B/SH-03B/SH-02B/SH-01B
SH-08A/SH-07A/SH-06A/SH-05A/SH-04A/SH-02A/SH-03A/SH-01A/SH906iTV
SH906i/SH905iTV/SH905i/SH904i/SH903iTV/SH903i/DOLCE SL (SH902iSL)
SH902iS/SH902i/SH901iS/SH901iC/DOLCE (SH851i)/SH706iw/SH706ie/SH706i
SH705iII/SH705i/SH704i/SH703i/SH702iS/SH702iD

Motorola

M1000

富士通

F-01G/F-08F/F-07F/F-01E/F-06D/F-04D/F-02D/F-10C/F-05C/F-04C/F-03C/F-02C
F-01C/F-09B/F-10B/F-08B/F-07B/F-06B/F-04B/F-03B/F-02B/F-01B/らくらくホン(F-10A)
F-08A/F-09A/らくらくホン(F-07A)/F-04A/F-03A/F-02A/F-01A/F1100/F906i/F905i
F904i/F903iX/F903i/F902iS/F902i/F901iS/F901iC/らくらくホン(F884iES)
らくらくホン(F884i)/らくらくホン(F883iES)/らくらくホン(F883i)/らくらくホン(F882iES)/F801i
F706i/F705i/F704i/F703i/F702iD

LG

L-10C/L-01C/L-04B/L-03B/L-02B/L-01B/L-06A/L-04A
L-03A/L-01A/L706ie/PRADA(L852i)/L705iX/L705i/L704i
L602i/SIMPURE L1(L601i)/SIMPURE L(L600i)

SonyEricsson

SO906i/SO905iCS/SO905i/SO903iTV/SO903i/SO902iWP+/SO902i/SO706i/SO705i
SO704i/SO703i/SO702i

三菱

D905i/D904i/D903iTV/D903i/D902iS/D902i/D901iS/D901i/らくらくホン(D880SS)
Music Porter X (D851iWM)/D800iDS/D705i μ /D705i/D704i/D703i/D702iF/D702i
Music Porter II(D701iWM)/D701i

SANYO

SA702i/SA800i

au

※該当品番 : MB-30 / MB-32 / MB-77

SonyEricsson

URBANO AFFARE (SOY05)/iida G11(SOX02)/URBANO MOND(SOY04)/S007/S006
BRAVIA(S005)/BRAVIA(S004)/Cyber-shot (S003)/URBANO BARONE(SOY03)
BRAVIA U1(SOY02)/S002/iida G9(SOX01)/Cyber-shot (S001)/Premier 3(SOY01)
Xmini(W65S)/Cyber-shot (S001)/Premier 3(SOY01)/Xmini(W65S)/W64S/re(W63S)/W61S
W62S/W54S/W53S/W52S/W51S/W44S/W43S/W42S/W41S/W32S/W31S

CASIO

G'z One TYPE-X (CAY01)/CA007/CA006/CA005/CA004/CA003/G'zone (CA002)
CA001/W63CA/W62CA/W61CA/W53CA/W52CA/W51CA
W43CA/G'zone(W42CA)/W41CA/W31CA/G'zone(A5513CA)/A5512CA

SHARP

SH011/SH010/SH009/SH008/SOLAR(SH007)/SH006/SH005
SH004/SH003/SH002/Sportio water beat(SHY01)/SH001
W64SH/W63SH/W62SH/W61SH/W52SH/W51SH/W41SH

パンテック

PT001/W62PT/A1407PT/A1406PT/A1405PT

SANYO

SA002/SA001/W64SA/W63SA/W61SA/W54SA/W62SA/INFOBAR 2(W55SA)/A5527SA
W53SA/W52SA/A5525SA/Sweets cute (A5524A)/W51SA/W43SA/W42SA/A5522SA
W33SAII/W32SA/W41SA/Sweets pure (A5519SA)/A5518SA/W33SA/A5514SA
Sweets (A5510SA)/W31SA/W31SA II /A5507SA/A5508SA/A5505SA/A5503SA

東芝

E09F/iida X-RAY(TSX06)/iida LIGHT POOL(TSX05)/T005/T006/T007/T008
T004/T003/iida PLY(TSX01)/biblio(TSY01)/T002/T001/W65T/W64T/W63T/W62T
W61T/W56T/W55T/A5529T/W54T/W53T/W52T/W51T/A5523T/DRAPE (W46T)
W47T/W45T/W44T/W43T/neon(W42T)/W41T/W32T/A5517T/A5516T/W31T
A5511T/A5509T/A5506T/A5501T

京セラ

K011/K012/K010/K009/K008/K007/K006カメラ無し
K006/K005/iida lotta(KYX04)/iida PRISMOID(KYX03)/K004/K003/iida misora (KYX02)
K002/NS01/K001/W65K/W63K/W64K/W62K/W61K/W53K/MEDIA SKIN(W52K)
W51K/W44K/W43K/W42K/W41K/W32K/W31KII/W31K/A101K/A5528K/A5526K
A5521K/A5515K

日立

beskey(HIY02)/Hi-Vision Cam(HIY01)/H001/W63H/W62H/W61H/W53H/W52H/W51H
W43H/W42H/W41H/W32H/PENCK(W31H)

Panasonic

PT002/P001/W62P/W61P/W52P/W51P

SoftBank

※該当品番 : MB-31 / MB-33 / MB-78

SHARP

301SH/202SH/109SH/108SH/008SH/004SH/002SH/001SH/DM007SH/DM008SH
945SH/944SH/943SH/942SH/941SH/940SH/936SH/935SH/934SH/933SH/932SH
931SH/930SH/923SH/922SH/921SH/920SH/913SH/912SH/910SH/911SH/905SH
904SH/903SH/831SH/PANTONE (830SH)/825SH/824SH/823SH/822SH/821SH
820SH/816SH/843SH/842SH/841SH/841SHs/840SH/832SH/815SH
PANTONE(812SH)/811SH/810SH/804SH/705SH/703SHf/703SH

東芝

921T/920T/912T/911T/910T/904T/903T/832T/824T/823T/822T/821T/820T
815T/814T/813T/812T/811T/810T/803T/705T

Panasonic

401PM/301P/103P/001P/002P/002P for Biz/942P/941P/940P/931P/930P/921P
920P/842P/841P/840P/831P/830P/824P/823P/822P/820P/810P/705P

NEC

001N/940N/931N/930N/840N/841N/831N/830N/820N/821N/804N/741N/703N

カシオ

930CA/830CA

サムスン

001SC/941SC/840SC/931SC/740SC

ZTE

840Z